

2. Multifunction Valve:



The Multi function valve, located on the LPG Tank, controls a number of operations such as 80% filling restriction, level indication, remote controlled solenoid valve, Excess pressure relief valve, Thermo fusible plug and Excess flow control valve.

Manual cock is also an integral part of the multi-functional valve. Available on 30° & 90° orientation for all sizes.

Approval: IS 15100